

# ADAS Installation & Calibration

- Recommended installation height range of ADAS: **150cm~240cm**.
- Allows installation height range of ADAS: **120cm~260cm**.
- Locate on the horizontal center line of the vehicle.
- Keep the vehicle parked on the flat ground to keep the lens horizontal to the ground level during installation.

- The ADAS camera is requested to installation in the middle of the front windshield without affecting the driver's line of sight.
- If the vehicle comes off the swiper as below (photo), the ADAS camera should be installed in the swiping area. Ensure the ADAS camera installation area (especially the lens) can be cleaned in the rainy weather. But the ADAS camera can not be covered by the stationary swiper as this will affect ADAS working.
- If the vehicle comes with a wiper in the middle of the windshield (e.g. below vehicle), The ADAS camera can be installed within the working area of the left and right wipers and ensure the ADAS camera (especially the lens) installation area glasses can be cleaned in the rainy weather.

From:

<http://eu.streamax.com:8800/> - Europe\_Wiki

Permanent link:

[http://eu.streamax.com:8800/doku.php?id=public:ai:adas\\_installation\\_and\\_calibration&rev=1601203833](http://eu.streamax.com:8800/doku.php?id=public:ai:adas_installation_and_calibration&rev=1601203833)

Last update: **2020/09/27 12:50**

