

Ceiba2 Web Client

Ceiba2 can be login via your favorite web browser which supportsHTML5. Default links as “server IP address/ domain name + 12056”, e.g “<http://192.168.60.218:12056>”.

h

LiveView

Similar to Ceiba2 PC client software operations, Double click on your favorite vehicle or channel to open live view / live stream.

h

Playback and export the footage

In the “Playback” menu, double click on your favorite vehicle and date to search for the playback. Hit the “cloud” for clip footage to your local PC. Please note the flash player need to be enabled on this page.

h

Add vehicle, fleet, and user

The same process as PC client but a different GUI.

From:

<http://eu.streamax.com:8800/> - Europe_Wiki

Permanent link:

http://eu.streamax.com:8800/doku.php?id=public:ceiba2:ceiba2_faq&rev=1602570747

Last update: 2020/10/13 08:32

